

AUIN00476 Intergrain UltraDeck Timber Oil on New Accoya - Treated timber [Exterior]

Description

This specification is a generic exterior finishing system for Accoya treated timber with Teknos AQUAPRIMER 2900-08 in all applications.
The recommendation for 3 coats of topcoat is mandatory for external coastal locations.

Substrate and Substrate Preparation

Substrate Notes

Accoya® wood is Radiata Pine timber that has undergone an acetylation process which increases the durability of the timber. While Accoya® wood is stronger than untreated Radiata Pine, it must be treated for protection against black mould. All end grain must be sealed to prevent water ingress.

Substrate Preparation Notes

Pre-primed Accoya timber with Teknos Aquaprimer 2900-08 Primer Sealer Undercoat

Surface Contaminants:




- Light soiling and dust: Wipe down with a clean water damp cloth and allow to dry
- Heavy soiling: Examine the surface for the presence of sap, grease, oil, wax, tannin, building marks, or other contaminants. Scrape off and use scraper to remove dirt and mortar splashes. Clean the timber with a suitable timber cleaner such as Intergrain Ultraprep Timber Cleaner Garden Safe, following pack directions for dilution and application recommendations. Rinse off with clean fresh water and allow surface to dry prior to topcoat




End Grain:

Any exposed end grain must be coated with the desired topcoat, noting minimum number of topcoats required.

Coating System Summary




- | | |
|------------|---|
| • Primer | Teknos Aquaprimer 2900-08 Primer Sealer Undercoat |
| • 1st Coat | Intergrain UltraDeck Timber Oil |
| • 2nd Coat | Intergrain UltraDeck Timber Oil |
| • Optional | Intergrain UltraDeck Timber Oil |

Coating System			
Primer — Teknos Aquaprimer 2900-08 Primer Sealer Undercoat			
Coat Type Primer	Datasheet AUTE00034 Teknos Aquaprimer 2900-08 Primer Sealer Undercoat		
Read the full Datasheet details at Teknos Aquaprimer 2900-08 Primer Sealer Undercoat			
Application Methods			
 Spray  Brush  Roller			
Factory Applied System			
	Min	Max	Recommended
Theoretical Spread Rate (m²/L)	<input type="text" value="12"/>	<input type="text" value="13"/>	<input type="text"/>
Wet Film Per Coat (microns)	<input type="text" value="75"/>	<input type="text" value="100"/>	<input type="text"/>
Recoat Time **	<input type="text" value="1"/>	<input type="text" value="3"/>	<input type="text" value="2"/>
V.O.C. Level < 20gm/lit		Meets GBCA V.O.C. Requirements? Yes Total Volatile Organic Content (TVOC) values are calculated in accordance to the stated methodology within Green Star Technical Manuals. The TVOC content is theoretically calculated as the sum total of the known VOC values of the product's raw material components. These materials include the base paint plus additional low VOC tinter required for non-factory packaged colours.	
Coating Application Details Product is supplied ready for use. Stir thoroughly prior to use. Dipping, flow coating, saturation spray, brush and machine application is also possible. Sanding and overcoating: 3 hours ambient conditions 23C 50% Relative humidity. To eliminate grain raise, lightly sand with P240 grit sandpaper removing residual dust prior to top coating.			
Additional Coating Details This product is factory applied by M&B Sales in accordance with the manufacturer's recommendations			
SDS Number DLXGHSEN004609		SDS Link View SDS Link	

1st Coat — Intergrain UltraDeck Timber Oil			
Coat Type 1st Coat	Datasheet AUIN00038 Intergrain UltraDeck Timber Oil		
Read the full Datasheet details at Intergrain UltraDeck Timber Oil			
Application Methods			
 Spray  Brush  Pad			
	Min	Max	Recommended
Theoretical Spread Rate (m²/L)	<input type="text" value="10"/>	<input type="text" value="14"/>	<input type="text"/>




Wet Film Per Coat (microns)	72		
Dry Film Per Coat (microns)	15		
Recoat Time **	See below		
V.O.C. Level <30g/L		Meets GBCA V.O.C. Requirements? Yes Total Volatile Organic Content (TVOC) values are calculated in accordance to the stated methodology within Green Star Technical Manuals. The TVOC content is theoretically calculated as the sum total of the known VOC values of the product’s raw material components. These materials include the base paint plus additional low VOC tinter required for non-factory packaged colours.	
<div>Coating Application Details</div> <div>Remove excess water from the surface and allow the timber to dry for at least 1 hour before coating. Stir Intergrain UltraDeck Timber Oil thoroughly before and during use with a flat blade stirrer.</div> <div>Apply Intergrain UltraDeck Timber Oil using the Intergrain DeckBrush (recommended), flat deck applicator, paint brush or spray (air assisted airless or airless). Do not use a roller.</div> <div>Apply at the coverage rate of 10-14m2/L. Do not overspread or apply thinly as insufficient film thickness will result in lap marks and compromise performance and durability. When coating large areas, work in sections, apply long strokes and use natural breaks in the boards as stopping points. If spraying, it is recommended to back brush to even out the finish and avoid spotting.</div> <div>Allow to dry following the recoat time indicated in the section typical properties, then apply a second coat. If necessary, sand lightly between coats to remove any raised grain.</div> <div>A third coat will give extra protection and is required in harsh conditions such as full sun exposure, around pools and in humid areas or if the first coat was applied on damp or porous timber.</div> <div>Important: All timber is required to be free from dust, mould and site contaminants prior to coating. Follow all relevant product label instructions when using Intergrain products.</div> <div>Maintenance Conduct a routine 12 monthly maintenance inspection. Best protection of the timber and ease of maintenance is ensured if Intergrain UltraDeck Timber Oil is recoated before deterioration of the coating and timber underneath occurs.</div> <div>Help & advice Australia – 1800 630 285 www.intergrain.com.au NZ – 0800 222 687 www.intergrain.co.nz For detailed project specifications or a Safety Data Sheet, contact Intergrain Help & Advice or visit our website.</div>			
SDS Number DLXGHSEN003480		SDS Link View SDS Link	

2nd Coat — Intergrain UltraDeck Timber Oil

Coat Type 2nd Coat	Datasheet AUIN00038 Intergrain UltraDeck Timber Oil		
Read the full Datasheet details at Intergrain UltraDeck Timber Oil			
Application Methods			
<div><div> Spray</div><div> Brush</div><div> Pad</div></div>			
Theoretical Spread Rate (m²/L)	Min 10	Max 14	Recommended

Wet Film Per Coat (microns)	72		
Dry Film Per Coat (microns)	15		
Recoat Time **	See below		
V.O.C. Level <30g/L		Meets GBCA V.O.C. Requirements? Yes Total Volatile Organic Content (TVOC) values are calculated in accordance to the stated methodology within Green Star Technical Manuals. The TVOC content is theoretically calculated as the sum total of the known VOC values of the product’s raw material components. These materials include the base paint plus additional low VOC tinter required for non-factory packaged colours.	
<p>Coating Application Details</p> <p>Remove excess water from the surface and allow the timber to dry for at least 1 hour before coating.</p> <p>Stir Intergrain UltraDeck Timber Oil thoroughly before and during use with a flat blade stirrer.</p> <p>Apply Intergrain UltraDeck Timber Oil using the Intergrain DeckBrush (recommended), flat deck applicator, paint brush or spray (air assisted airless or airless). Do not use a roller.</p> <p>Apply at the coverage rate of 10-14m2/L. Do not overspread or apply thinly as insufficient film thickness will result in lap marks and compromise performance and durability. When coating large areas, work in sections, apply long strokes and use natural breaks in the boards as stopping points. If spraying, it is recommended to back brush to even out the finish and avoid spotting.</p> <p>Allow to dry following the recoat time indicated in the section typical properties, then apply a second coat. If necessary, sand lightly between coats to remove any raised grain.</p> <p>A third coat will give extra protection and is required in harsh conditions such as full sun exposure, around pools and in humid areas or if the first coat was applied on damp or porous timber.</p> <p>Important: All timber is required to be free from dust, mould and site contaminants prior to coating. Follow all relevant product label instructions when using Intergrain products.</p> <p>Maintenance</p> <p>Conduct a routine 12 monthly maintenance inspection.</p> <p>Best protection of the timber and ease of maintenance is ensured if Intergrain UltraDeck Timber Oil is recoated before deterioration of the coating and timber underneath occurs.</p> <p>Help & advice</p> <p>Australia – 1800 630 285 www.intergrain.com.au</p> <p>NZ – 0800 222 687 www.intergrain.co.nz</p> <p>For detailed project specifications or a Safety Data Sheet, contact Intergrain Help & Advice or visit our website.</p>			
SDS Number DLXGHCEN003480		SDS Link View SDS Link	

Optional — Intergrain UltraDeck Timber Oil

Coat Type Optional		Datasheet AUIN00038 Intergrain UltraDeck Timber Oil	
Read the full Datasheet details at Intergrain UltraDeck Timber Oil			
Application Methods			
<div><div></div><div>Spray</div><div></div><div>Brush</div><div></div><div>Pad</div></div>			
Theoretical Spread Rate (m²/L)	Min 10	Max 14	Recommended

Wet Film Per Coat (microns)	72		
Dry Film Per Coat (microns)	15		
Recoat Time **	See below		
V.O.C. Level <30g/L		Meets GBCA V.O.C. Requirements? Yes Total Volatile Organic Content (TVOC) values are calculated in accordance to the stated methodology within Green Star Technical Manuals. The TVOC content is theoretically calculated as the sum total of the known VOC values of the product’s raw material components. These materials include the base paint plus additional low VOC tinter required for non-factory packaged colours.	
<p>Coating Application Details</p> <p>Remove excess water from the surface and allow the timber to dry for at least 1 hour before coating. Stir Intergrain UltraDeck Timber Oil thoroughly before and during use with a flat blade stirrer.</p> <p>Apply Intergrain UltraDeck Timber Oil using the Intergrain DeckBrush (recommended), flat deck applicator, paint brush or spray (air assisted or airless). Do not use a roller.</p> <p>Apply at the coverage rate of 10-14m2/L. Do not overspread or apply thinly as insufficient film thickness will result in lap marks and compromise performance and durability. When coating large areas, work in sections, apply long strokes and use natural breaks in the boards as stopping points. If spraying, it is recommended to back brush to even out the finish and avoid spotting.</p> <p>Allow to dry following the recoat time indicated in the section typical properties, then apply a second coat. If necessary, sand lightly between coats to remove any raised grain.</p> <p>A third coat will give extra protection and is required in harsh conditions such as full sun exposure, around pools and in humid areas or if the first coat was applied on damp or porous timber.</p> <p>Important: All timber is required to be free from dust, mould and site contaminants prior to coating. Follow all relevant product label instructions when using Intergrain products.</p> <p>Maintenance Conduct a routine 12 monthly maintenance inspection. Best protection of the timber and ease of maintenance is ensured if Intergrain UltraDeck Timber Oil is recoated before deterioration of the coating and timber underneath occurs.</p> <p>Help & advice Australia – 1800 630 285 www.intergrain.com.au</p> <p>NZ – 0800 222 687 www.intergrain.co.nz</p> <p>For detailed project specifications or a Safety Data Sheet, contact Intergrain Help & Advice or visit our website.</p>			
SDS Number DLXGHSEN003480		SDS Link View SDS Link	

Disclaimer

This Specification is copyright to DuluxGroup (Australia) Pty Ltd and/or DuluxGroup (New Zealand) Pty Ltd (collectively, 'Dulux'). It may not be varied or altered without the prior written consent of Dulux, and if it is, Dulux has no responsibility or liability for those variations.

Unless Dulux has provided you with a customised, project-specific specification, this Duspec+ document does not represent that any particular product or product system will be suitable for your project.

Any information provided in this Duspec+ is given in good faith and is believed by Dulux to be correct at the time of publication. Products and coating systems can be expected to perform as indicated in this Duspec+ document, provided the substrate is in good condition, the coatings are applied by a suitably experienced and skilled applicator, and the preparation, application and maintenance is followed strictly as set out in this Duspec+ document, and as recommended on the applicable Dulux Product Data Sheet and Safety Data Sheets for the relevant products (available from www.duspecplus.com.au). Climatic conditions at application time can affect Duspec+ documentation suitability and product performance.

The correct colour or colour match is the responsibility of the applicator. Colours will change over time and Dulux does not guarantee that the same colour newly mixed will match a colour applied earlier which has been subjected to weathering or other change elements. No product colour is guaranteed against colour change.

Where any liability of Dulux in respect of this Specification cannot by law be excluded, Dulux's liability is limited, as permitted by law and at Dulux's option, to resupply of the relevant products or services or to reimbursing the cost of those products or services.

WHERE LEAD MAY BE PRESENT: The asset manager is responsible for verifying the presence of lead and determining whether to remove or encapsulate the lead. If lead is present, the work must be done in strict accordance with AS 4361 Parts 1 and 2 and Worksafe Australia guidelines.